


**U91014 UDG ULTIMATE FLIGHT CASE XXL BLACK PLUS
INTERNAL PADDING GUIDANCE****EQUIPMENT**

PIONEER DDJ S1/T1 : **REMOVE PADDING**

PIONEER DDJ RX : **REMOVE PADDING**

PIONEER DDJ SX/SX2 : **REMOVE PADDING**

PIONEER DDJ SR : **A1 + B1 + C1 + A2 + B2 + C2**

PIONEER DDJ ERGO : **A1 + B1 + D1 + A2 + B2 + D2**

PIONEER XDJ R1 : **B1 + D1 + B2 + D2**

PIONEER XDJ AERO : **B1 + D1 + B2 + D2**

ROLAND DJ-808 : **A1 + A2**

NUMARK 4TRACK : **A1 + A2**

NUMARK Ns6 : **A1 + A2**

NUMARK MIXDECK QUAD : **B1 + B2**

NUMARK iDJ Pro : **A1 + B1 + D1 + A2 + B2 + D2**

NUMARK N4 : **A1 + B1 + A2 + B2**

DENON MC-7000 : **A1 + A2**

DENON MCX-8000 : **REMOVE PADDING**