

User Manual

Mic and 1-button controller

The microphone is placed on the right headphone wire, and has 1-button. When used with an iPhone the button works with a single push to answer incoming calls and to hang up. When used with all Apple players the 1-button functions with a single push to play or stop the music. Push the button twice and it will forward to the next tracks. Push the button three times and it will go back to the previous track.

Protecting your hearing

Set the volume to low before you place the headphones on your ears. Do not listen at high yolume levels as it can lead to permanent hearing loss. Do not increase the volume once a comfortable level has been selected. Your ears will adapt as you continue to listen and if you increase the volume level, you may be causing damage to your ears without feeling discomfort.

Warranty

AIAIAI ApS warrants this product against defects in material or workmanship for a period of 3 years from the date of original purchase from an authorized AIAIAI distributor or reseller.

AIAIAI will repair or replace the defective product at its discretion if returned within the warranty period to our service facility.

This warranty is in lieu of all other warranties, expressed or implied, including, but not limited to, any implied warranty of merchantability or fitness for a particular purpose.

AIAIAI shall have no liability of any kind for any direct, indirect, incidental or consequential damages or expenses that arise from the use of this product.

We don't cover normal wear and tear or blown speakers, cut cords, bent jacks, torn headbands, loss or theft. You will void your warranty if you disassemble your headphones or dip them in water. If you believe this product is defective within the warranty period, repack the unit and return it postage prepaid to address below or contact us and we'll do what we can to resolve the problem.

Address

AIAIAI ApS · Studiestraede 31 DK-1455 · Copenhagen K · Denmark

Contact

supportgroup@aiaiai.dk



